

16x62 Robot Quick Reference

Basic Commands

Methods of RobotController (for talking to the Robot)

```
int serialOpen()

int serialClose()

int turnSonarsOn()

int turnSonarsOff()

int GS()

int setVel(int leftVel, int rightVel)

int killMotors()

int setAccel(int leftAccel, int rightAccel)

int configureSonars(int firingRate, int[] sonarOrder) -- 16 elements!!!

int setTimeout(int timeout)
```

Sensor Information: State_Array in RobotController

- Index 1-16: The sixteen sonar values, starting out front, going counter-clockwise
- Index 17: X integrated position
- Index 18: Y integrated position
- Index 19: Theta integrated position
- Index 20: Right wheel measured velocity
- Index 21: Left wheel measured velocity
- Index 22: Bumper status

Other Commands

SonarConsole - makes a sonar graphic display

DrawSonars(your_RobotController) - method that redraws the sonars.